



Notes:

1- All threaded connection points between Sch. 40 PVC and Sch. 80 PVC fitting shall be installed using teflon tape.

2- Contractor shall compact soil around rotor and riser prior to planting, plugging, seeding, or laying of sod.



ROTOR SPRAYHEAD